ozone

STRIKE X30

## MECHANICAL PRO GAMING KEYBOARD

USER MANUAL

STRIKE X30
MECHANICAL GAMING KEYBOARD

The Unbeatable One. Strike X30 is a RGB backlit mechanical keyboard with amazing on-the-fly configurations and LED modes whilst at the same time maintaining an elegant minimalist look and feel. Choose from 10 lighting effects, 10 customizable color-maps and configurable G-Mode functions to adapt and transform Strike X30 into your unique gaming style

Lighting effects controls

Playback Function Keys

Lighting effects

Two different heights
of keyboard legs

Keycap remover tool

STRIKE X30
KEY FUNCTIONS

- Fully 104 mechanical switched Gaming Keyboard with back-lighting effects

- Press ⊘ + **F12** on keyboard to set the lighting effect

1. Wave
2. Pinwheel
3. Breathing
4. Static
5. Rain drop reactive
6. Explosion
7. Extension
**8. Cyclone**
9. Scanning
10. Disable LED

- Press ⊘ + **F1** on keyboard to set the light direction effect

- Press ⊘ + **F2** on keyboard to set the lighting effect fixed color up to 9 times

- Multimedia shortcut keys on keyboard
 Press ⊘³ key for media playback functions

⊘³	+	F5 ▶/ll **Play**	F6 ■ **Stop**	F9 🔇 **Mute**
			F7 ◄◄ **Previous Track**	F10 ◄- **Volume -**
			F8 ►►l **Next Track**	F11 ◄+ **Volume +**

- Press ⊘³ **+ F3 or F4** on keyboard to increase or decrease back lighting brightness in 5 different levels
  Default Mode: 100% Brightness

⊘³ + F3 ☼ F4 ☼

- Gaming Mode: Press ⊘³ **+ Windows key** on keyboard to enter gaming mode (G-Mode) and block windows key.

⊘³ + ⊞🔒

Additional gaming features:

⊘³ + PAGE UP   ⊘³ + Page up to set 6 keys anti-ghosting

⊘³ + PAGE DOWN   ⊘³ + Page down to set N-keys rollover

⊘³ + W   ⊘³ + W to switch between arrow keys and WASD functions

● Press 🖲 + **ESC** on keyboard to start the macro editor (Only under G-mode). The keyboard backlit will shut off and the ESC and WIN keys light up as REC indicator. Choose any key to record by 🖲 + **Key**, when C/N/S LED blinking, insert a series of key strokes (Max 64 Strokes) to record a macro. When finish press again 🖲 + **Key** to stop and save. Keys with asigned macros light-up in red. Push 🖲 + **Assigned Key** to clear macro. Finally push 🖲 + **ESC** to exit macro editor. (🖲, **Win, Menu and Esc** are not editable keys)

🖲 + ESC   1st : **Enter Macro mode (Backlit off and** [ESC][WIN] **light-up)**

🖲 + KEY   2nd : **When C/N/S LED blinking, insert the macro key stroke series (Max 64 strokes)**

🖲 + KEY   3rd : **To stop and save the macro**

🖲 + ESC   4th : **To exit Macro mode**

● Press 🖲 + **1, 2, 3, 4 or 5** on keyboard to select a pre-defined color key mapping profile.

● Press 🖲 + **6, 7, 8, 9 or 0** on keyboard to select an user-defined color key mapping profile.

🖲 + [~]   **To start recording, PRINT starts to breath as REC**

🖲 + [F2]   **Select the keys you want to map, and push** 🖲 + F2 **to change the color**

🖲 + [~]   **To stop recording**

● Hold ☿ + **Print 3 Sec** on keyboard to set the RGB Hue. Print flashing as RGB Hue control indicator.

INSERT	DELETE		HOME	END		PAGE UP	PAGE DOWN

Red +/-
Flash when reaching
Max & Min Value

Green +/-
Flash when reaching
Max & Min Value

Blue +/-
Flash when reaching
Max & Min Value

Hold ☿ + **Print 3 Sec** on keyboard to finish the RGB Hue settings
Push ☿ + **Print** on keyboard to apply the RGB Hue settings to all keys

● Hold ☿ + **Esc, then press F1, release and F3, release and finally F5** on keyboard to reset the keyboard to factory settings.

ozone

its all about EVOLUTION